

Federal Communications Commission

§ 11.21

EAT, tests, or State and Local Area alerts. It is issued by the FCC and contains instructions for the above situations. A copy of the Handbook must be located at normal duty positions or EAS equipment locations when an operator is required to be on duty and be immediately available to staff responsible for authenticating messages and initiating actions.

[70 FR 71033, Nov. 25, 2005]

§ 11.16 National Control Point Procedures.

The National Control Point Procedures are written instructions issued by the FCC to national level EAS control points. The procedures are divided into sections as follows:

(a) *National Level EAS Activation*. This section contains the activation and termination instructions for Presidential messages.

(b) *EAS Test Transmissions*. This section contains the instructions for testing the EAS at the National level.

(c) *National Information Center (NIC)*. This section contains instructions for distributing United States Government official information messages after completion of the National Level EAS activation and termination actions.

[59 FR 67092, Dec. 28, 1994, as amended at 67 FR 18508, Apr. 16, 2002]

§ 11.18 EAS Designations.

(a) National Primary (NP) is a source of EAS Presidential messages.

(b) Local Primary (LP) is a source of EAS Local Area messages. An LP source is responsible for coordinating the carriage of common emergency messages from sources such as the National Weather Service or local emergency management offices as specified in its EAS Local Area Plan. If it is unable to carry out this function, other LP sources in the Local Area may be assigned the responsibility as indicated in State and Local Area Plans. LP sources are assigned numbers (LP-1, 2, 3, etc.) in the sequence they are to be monitored by other broadcast stations in the Local Area.

(c) State Primary (SP) is a source of EAS State messages. These messages can originate from the Governor or a designated representative in the State

Emergency Operating Center (EOC) or State Capital. Messages are sent via the State Relay Network.

(d) State Relay (SR) is a source of EAS State messages. It is part of the State Relay Network and relays National and State common emergency messages into Local Areas.

(e) Participating National (PN) sources transmit EAS National, State or Local Area messages. The EAS transmissions of PN sources are intended for direct public reception.

[59 FR 67092, Dec. 28, 1994, as amended at 77 FR 16700, Mar. 22, 2012]

§ 11.20 State Relay Network.

This network is composed of State Relay (SR) sources, leased common carrier communications facilities or any other available communication facilities. The network distributes State EAS messages originated by the Governor or designated official. In addition to EAS monitoring, satellites, microwave, FM subcarrier or any other communications technology may be used to distribute State emergency messages.

§ 11.21 State and Local Area plans and FCC Mapbook.

EAS plans contain guidelines which must be followed by EAS Participants' personnel, emergency officials, and National Weather Service (NWS) personnel to activate the EAS. The plans include the EAS header codes and messages that will be transmitted by key EAS sources (NP, LP, SP and SR). State and local plans contain unique methods of EAS message distribution such as the use of the Radio Broadcast Data System (RBDS). The plans must be reviewed and approved by the Chief, Public Safety and Homeland Security Bureau, prior to implementation to ensure that they are consistent with national plans, FCC regulations, and EAS operation.

(a) The State EAS Plan contains procedures for State emergency management and other State officials, the NWS, and EAS Participants' personnel to transmit emergency information to the public during a State emergency using the EAS. State EAS Plans should include a data table, in computer readable form, clearly showing monitoring